



Cricut[®] Machines

The Cricut machines are a fast and convenient way to cut letters, shapes, and phrases at the touch of a button! These electronic machines use small, compact font and shape cartridges to operate, allowing customization of the size and style of every design. The machines cut easily through a variety of materials, from paper to vinyl and chipboard to thin plastics. With no need for a computer, Cricut machines fit anywhere in a home, office, or classroom.

Original Cricut Personal Electronic Cutter

This portable machine uses 6" x 12" cutting mats to cut characters from 1" to 5.5" tall or 11.5" wide in paper, cardstock, vinyl, vellum, and thin plastics. Machine set includes a cartridge, cutting mat, cutting blade and necessary cords and manuals.

Cricut Create[®] Personal Electronic Cutter

This clever machine combines the portability of the original Cricut machine with the functionality of the Cricut Expression[®] machine. It allows cuts from 0.25" up to 11.5" on a 6" x 12" cutting mat, offers several modes and functions, and utilizes a large display screen. Machine set includes a cartridge, cutting mat, cutting blade and necessary cords and manuals.

Cricut Expression[®] 24" Personal Electronic Cutter

This machine uses cutting mats measuring 12" x 12" and 12" x 24" to allow cuts from 0.25" up to an impressive 23.5". Six modes and four functions offer greater customization of cuts, and new settings and menus add functionality to the machine. Machine set includes two cartridges, 12" x 12" cutting mat, cutting blade and necessary cords and manuals.

Cricut Imagine[™] Electronic Print and Cut System

Cricut Imagine lets you design, print, and cut together to take all of your creative projects to the next level. Now you can add full color and patterns for one-of-a-kind projects that reflect your creativity and personality. Cricut Imagine offers endless possibilities; the rest is up to you. Machine set includes one Cricut Imagine cartridge, 12" x 12" cutting mat, cutting blade, ink and necessary cords and manuals.





Cricut Machines	Original Cricut®	Cricut Create®	Cricut Expression®	Cricut Imagine™
Machine Size and Weight	7" tall x 15.5" wide x 6.75" deep. 9.78 lbs, with power cord 10.53 lbs	7" tall x 15.5" wide x 6.875" deep. 10.00 lbs with power cord 10.75 lbs	7" tall x 21.25" wide x 7.5" deep. 12.65 lbs, with power cord 13.40 lbs	6.8" tall x 24.3" wide x 13.37" deep. 28.15 lbs, with power cord 29.35 lbs
Maximum Cut Area	6" x 12"	6" x 12"	12" x 24"	12" x 12"
Use with Cricut DesignStudio®	•	•	•	
Use with Gypsy™	•	•	•	•
Use with Cricut Jukebox®	•	•	•	•
Use with all Original Cricut Cartridges	•	•	•	•
Use with Cricut Imagine Cartridges				•
Portrait/Landscape Mode		•	•	
Auto Fill Mode		•	•	•
Fit to Page Mode		•	•	•
Center Point Function		•	•	
Flip Function		•	•	•
Mix n' Match Mode			•	•
Quantity Mode (For Cutting a Single Image)			•	•
Fit to Length Mode			•	
Multi Cut Function			•	•
Line Return Function			•	
Settings Menu			•	•
Mat Size Feature			•	
Material Size Function			•	•
Print and/or Cut				•
Print Color				•
Change Pattern/Color				•
12" x 12" Colored/Patterned Paper Printing				•
Project Quantity (For Cutting Multiple Images)				•
Pattern Caching				•
Border Colors for Images				•
Updatable and Expandable Features				•